

Parachute Packing Jig

Contents:

- 1 3/8" Plywood Comb (A)
- 1 3/8" Plywood Base (B)
- 1 3/8" Plywood Gate (C)
- 2 1/4 - 20 Thumbscrews
- 2 Washers
- 2 Clear Vinyl Spacers
- 9" 3/8" Foam Tape

Assembly Instructions:

1. Install a washer and then a vinyl spacer onto the two thumbscrews.
2. Glue the Comb (A) into the slot in the Base (B) using wood glue or epoxy. Wait until it is dry before moving on to step 3.
3. Install the Gate (C) onto the Comb (B) using the thumbscrews. The gate should be on the opposite side of the Comb from the pressed in T nuts.
4. Cut the foam tape into two 4.5" long pieces.
5. Remove the backing from the tape and install one piece centered on the bottom face of the Gate (C). Place the other piece of foam tape on the Base (B) against the comb and centered under the Gate (C).

