FRUITY CHUTES

Phantom 4 Bundle Quick Start Guide

Thank you for buying the Skycat Parachute Launcher Bundle for the Phantom 4. These resources are on our website. Here are direct links to help you get started!

WARNING: Be sure to go through each section carefully. Let us know if you have questions. In the event of an emergency, an improperly rigged parachute can result in a crashed drone.

3. Prepare the Parachute: Follow up to Step 22, then go to the next step of the Quick Start Guide: http://bit.ly/2ESa0FO

4. Pack and Prepare the P4 Launcher: http://bit.ly/2nMNWot

1. Phantom 4 Help: http://bit.ly/2BKPVCB

2. Assemble the P4 Mounting Bracket: http://bit.ly/2EdJvgT

Phantom 4 Bundle Quick Start Guide (cont.)

5. Using the SATS-MINI failsafe:
   http://bit.ly/32su0ce

Note: Unless otherwise indicated, SATS-MINI are shipped preconfigured for the Phantom 4. No setup or software upgrades are needed. We do recommend downloading and installing the Windows UI program "Shooty Chute." This lets you tune the settings as well as download and manage the black box flight log.

If you have any questions, please contact us at Fruity Chutes: http://bit.ly/2DLVz4G

6. Optional Product - Using the Skycat Rescue Radio:
   http://bit.ly/326s8Lu

Note: If you purchased the rescue radio option, the Nano receiver comes mounted inside the SATS-MINI case. The transmitter comes pre-bound to the Nano receiver. Activating the Rescue Radio parachute eject button (pressing silver button) will cause the SATS-MINI to eject the parachute. This is assuming the SATS-MINI is armed (the red mode light is flashing).

Be sure to ground test your setup!